#### Celia Wall Basin/Bath Mixer

## Nero



Versions:202401



### Installation Instruction



Fix body on noggin and ensure installation depth is 51-68mm from noggin to ceramic tile.
Connect cold water hose and hot water hose and conduct water pressure test for leakage.
Install plasterboard and ceramic tile after drilling a φ50 and a φ40 hole according to above picture.



#### 4. Remove the plastic sleeve, grub screw and water testing plug.



5.Install washer, plate, spout and handle.

www.nerotapware.com.au

# Nero

info@nerotapware.com.au nerotapware.com.au 11-13 Buontempo Road Carrum Downs Vic 3201

