Opal Twin Shower With Air Shower

Nero



Versions:202401



Nero — 2

Important

All products must be installed by licensed plumbers.

All pipework must be thoroughly flushed prior to installation, as foreign materials may block the flow regulating device and reduce the flow of water.





4. Locate and push shower rail assembly onto wall adaptors.Tighten grub screws firmly with allen key provided.Slide the back plates against the wall/tile face properly.

5.Screw shower head to shower arm with care. (Note the rubber washer in the shower head.)



6. Please noted the rubber washer in the hand shower.

Connect shower rail and hand shower with hose. TEST & CHECK FOR LEAKS.

www.nerotapware.com.au

Nero ------ 3

Nero

info@nerotapware.com.au nerotapware.com.au 11-13 Buontempo Road Carrum Downs Vic 3201

